



INSTALLATION INSTRUCTIONS

Part FTS750676

97-2006 Jeep Wrangler TJ / 2003-06 Jeep Rubicon
3-Way Adjustable Rear Replacement Sway Bar
for factory Dana 35 & Dana 44 axles

HARDWARE AND COMPONENTS LIST

<u>Carton 1 OF 1 (A)</u>	<u>Qty</u>
Components	
50-750676 Rear Sway Bar 19mm Diameter	1
EB5006 Rear D-Bushing	2
EB5010 Bushing Clamp	2



How to install -

- 1. Remove rear factory sway bar. Retain factory bolts.***
- 2. Pry open the bushings. Install D-bushings onto sway bar.***
- 3. Align new clamps with holes in axle and install sway bar using factory hardware. Tighten.***

Note: If installing sway bar with Full-Traction 3-link Upper V-bar mounting bracket, longer D-clamp bolts may be required.

The 3-position mounting holes in the end of the bar allow for adjustment of roll stiffness.